

Buffers for Tecan

1. 50/50 ACN
Acetonitrile and H₂O
2. 50/3X SSC Have 20X
Want
Have X Volume
Ex: 500 ml DMSO
 150 ml 3X SSC $\frac{3X}{20X} \times 1000 = 150 \text{ ml}$

 350 ml Milli Q H₂O
 1000ml
2. 50% DMSO
50% Milli Q H₂O